

Cadence Battery Replacement Instructions

Materials needed: Jewelers Screwdriver Size # 00, Precision tweezers, one lithium CR 2032 watch battery



Step 1. Remove the four screws from the stainless steel case back of the watch with a Jewelers screwdriver



Step 2. Remove the stainless steel case back from the watch



Step 3. Remove the clear plastic tape from the watch assembly. Once the tape is removed from the watch assembly, discard the tape. (*Do not to take the assembly out of the watch*)



Step 4. Unlatch the clip covering the CR 2032 battery



Step 5. Remove and replace the CR 2032 battery with a new lithium battery



Step 6. Check the clips next to each button to make sure they are still aligned properly



Step 7. Place the case back onto the watch (Make sure the writing on the back of the watch is not upside down)



Step 8. Securely tighten the four screws so the case back is flush with the watch .



NK
NIELSEN-KELLERMAN

Toll Free: 800-784-4221

Phone: 610-447-1555

Fax: 610.447.1577

www.nkhome.com

info@nkhome.com